



- STEPS:**
1. BEGIN INSTALLATION OF THE V-STRAPS AT A CORNER BETWEEN THE ENDWALL AND SIDEWALL AS SHOWN.
 2. INSTALL A WIRE CLIP IN THE V-STRAP ALONG THE ENDWALL.
 3. LOOP THE 3RD "DIAMOND" INTO THIS WIRE CLIP(ALONG THE ENDWALL).
 4. LOOP THE 5TH "DIAMOND" INTO THE NEXT WIRE CLIP ALONG THE ENDWALL.
 5. FROM THE WIRE CLIP IN THE CORNER COUNT OVER TWO KNOTS. AT THIS LOCATION GATHER THREE KNOTS AND LOOP THEM INTO THE WIRE CLIP(ALONG THE SIDEWALL).
 6. COUNTING ALONG THE SAME LINE OF KNOTS, COUNT OVER TWO KNOTS AND GATHER INTO WIRE CLIP(ALONG THE SIDEWALL).
 7. CONTINUE ALONG THE SIDEWALL EAVE MEMBER. SEE SIDEWALL DETAILS ON DWG. 1081345.

DETAIL A

GROUP	DRAWING NUMBER	REV.
01-019-01	B 1081344	00

 AISC Certified for Design & Fabrication	THIS PRINT SUBJECT TO CHANGE WITHOUT NOTICE. FOR BUILDING ERECTION ALWAYS USE THE PRINTS RECEIVED WITH THE BUILDING SHIPMENT.	SKY-WEB II™	MESH ATTACHMENT STARTING DETAIL	ALL BUILDINGS
		 BUTLER A BlueScope Steel Company	BUTLER MANUFACTURING COMPANY	DATE 09/28/98